

QUICK GUIDE

Konftel 70



OmniSound®




Good Choice!

We are glad that you have selected a quality product from Konftel. The **Konftel 70** is a sleek, flexible and easy-to-use speakerphone with dual connectivity that gives you the freedom to connect via Bluetooth® or USB. Expand with one of our cameras together with the Konftel OCC Hub and you will get a convenient video kit for all your video meetings.

For more than 30 years we have refined and developed our unique OmniSound®-technology to perfection. The **Konftel 70** leverages on those capabilities.

USE CASES DESCRIPTION]




USB
CONNECTIVITY



BLUETOOTH®
CONNECTIVITY

CONNECTIONS AND BUTTONS]



BLUETOOTH® INSTRUCTIONS]

To be able to connect the Konftel 70 to your mobile device they will first have to be paired. Pairing is only required when connecting for the first time. After that you may simply reconnect.

PAIRING


1. Press the Bluetooth® (📶) button for **2s**.
2. Start a search for Bluetooth®-devices on your mobile device.
3. Select Konftel 70 in the list of found devices. *Pairing will be completed within a few seconds.*

RECONNECT

1. Make sure Bluetooth® is enabled on your mobile device. Press the Bluetooth® (📶) button on the Konftel 70 **once**. *Reconnection will be completed within a few seconds.*

Note: Pairing and reconnecting can also be achieved using NFC. Simply tap your NFC-compliant device on the Konftel 70 NFC-tag.

LEDS FOR STATUS AND BATTERY]



CALL STATUS LEDS

- Green Call active / Outgoing call
- Green flashing Incoming call
- Red Microphone muted
- Red flashing Call on hold
- Blue Bluetooth® music mode

BLUETOOTH® LED

- Blue flashing Pairing / Reconnect
- Blue Connected

BATTERY LEDS

- Charging needed
- >10% battery
- >25% battery
- >50% battery
- >75% battery
- Fully charged with cable connected



Konftel is a Climate Neutral certified company. We have measured and offset our entire footprint of greenhouse gases, and are committed to reduce our emissions.