Strobe Light Flashes when VoIP / Electronic Phone Rings
(will also flash on intercom calls or paging through the phone)

**Viking Model SL-2
(DOD# 242)**

VOX Time Out Delay should be set to maximum time out (fully right).

VOX Trigger Sensitivity: Turn the pot to the left to decrease and the right to increase VOX trigger sensitivity.

Green

Red

Black

12

11

Strap

6

5

Talk Battery Switch

PP

2: Audio In

1: Audio In

The Talk Battery Switch should be set to PP (off).

Internal View of a Typical Key Set Phone

Power Input: 12V DC adapter included

Viking Model PI-1A (DOD# 490)

DOD# 913