


Quick Usage

Interface Introduction

Home Interface



No.	Description
1	Control access to different pages: Home/Phone/Contacts/Settings. - Home: The current page where you can start a meeting. - Phone: Make a phone call. - Contacts: Call a contact. - Settings: Configure device settings.
2	The local time.
3	Start a scheduled meeting.
4	Start an instant meeting.
5	Join a Zoom meeting by entering a meeting ID.
6	Share content from your laptop or mobile device.



7 Control the device using voice commands.

Meeting Interface




No.	Description
1	Meeting Information.
2	Meeting Controls.

Yealink RoomConnect Software Interface

You need to switch the system to Zoom Rooms mode (For more information, please refer to Switch Account. Open the Yealink RoomConnect application, and the software interface is as follows.





No.	Description
1	Display basic device information, and click to enter the device details setting.
2	Basic software information and device management server configuration.

2. General Feature

When the administrator completes the Quick Setup, the device can start working usually.

Description	Related Document
Start an instant meeting	[Instant Meeting](···\05. User Guide\00. Meeting\00. Instant Meeting.md)
Join the meeting	Join Meeting
Starting sharing via a cable	[Share Content via Cable](···\05. User Guide\01. Content Sharing\00. Share Content via Cable.md)
Starting sharing via the WPP20	Share Content via WPP20
Camera control	Basic Settings