


To charge

Connect the USB cable to a power adapter or a PC to charge the speakerphone.




© 2024 FANVIL Technology Co., Ltd.

All rights reserved. No parts of this publication may be reproduced or transmitted in any form or by any means, electronic or mechanical, photocopying, recording, or otherwise, for any purpose, without the express written permission of FANVIL Technology Co., Ltd.

Tel: +86-755-2640-2199 Email: sales@fanvil.com Web: www.fanvil.com
Fanvil Technology Co., Ltd.

Fanvil | LINKVIL


Quick Start



CS40


Conferencing Speakerphone

CS40 Conferencing Speakerphone



LED Bars (bilateral)


Bluetooth


Volume down



Mute


Volume up


Call

To use

Power ON/OFF: Hold Power button for 2s.



Bluetooth pairing:

Hold Bluetooth button for 1s to enter pairing mode.

Choose “Linkvil CS40” in the device discovery list on the PC or smartphone.

