


## 8188MEM Hydrophobic Membrane Screen Installation Sheet



Need Help?

(604) 454-3792 or [support@algosolutions.com](mailto:support@algosolutions.com)

## About the 8188MEM

The 8188MEM is a protective shield for indoor Algo 8188 SIP Ceiling Speakers and 8189 SIP Surface Mount Speakers that allows for extra protection in areas that may be exposed to moisture\* (e.g. bathrooms, locker rooms, and hospitals). The 8188MEM prevents electrical damage from water that may pass through the speaker in environments mentioned above. When using the 8188MEM both the Algo 8188 and 8189 will maintain their high quality sound. However, the sound from the microphone may be affected.

**\*Note:** The 8188MEM is not intended for use to protect the speaker from direct spray.

For more information about the Algo 8188 and 8189 please see the [8188 SIP Ceiling Speaker User Guide](#) or [8189 SIP Surface Mount Speaker Getting Started Sheet](#).

## Installing the 8188MEM

To install the 8188MEM, use the tool supplied (see right) with the Algo 8188, 8189, or 8188MEM to remove the grill on the 8188 or 8189 speaker. If lost, a small Allen key or heavy duty paperclip bent into an L shape can be used to remove the grill by pulling close to the edge. Once the grill is removed, place the 8188MEM onto the speaker, working your way around for a tight fit. The protective films on the 8188MEM needs to be removed before installation.

After installation and testing, gently work the speaker grill into its friction fit position and ensure it is evenly flush to the housing around the edge. The speaker grill is intentionally tight to prevent falling from the ceiling.



## 8188MEM Hydrophobic Membrane Screen

