

# PIVOT by Spectralink Call Server Interoperability

The tables below list the call servers that have been tested as interoperable with the Spectralink<sup>™</sup> 87-Series handsets. Only products listed in the table have been tested for compatibility and acceptable performance with PIVOT handsets. Spectralink does not recommend or support deployments with products not listed in the table. This document will be updated as additional call servers are tested. Interoperability documents are found on the <u>Spectralink 87-Series Support</u> page.

Note: All software is subject to significant change from version to version. Only those configurations listed in this document are supported by Spectralink.

#### **Direct Integration**

The following platforms have been tested with Spectralink 87-Series models.

•.		
Partner	Platform	PBX Software Version
Avaya	Communications Server 1000	7.5, 7.6
	Aura	6.1, 6.2, 6.3
	IP Office	9.0
AudioCodes	SPS GW w/Lync Integration	SPS Core: 3.0.31.38710
		SPS Switch: 3.0.25.35690
		Web Admin: 3.0.M.30.38031
Cisco	UCS	9.0, 10.5
Mitel	MiVoice Business 3300 ICP	Release 7.0
		Active Version: 13.0.0.80
NEC	UNIVERGE 3C *	8.5.3.11
ShoreTel	ShoreTel IP Phone System	14.2
SwitchVox	54165	5.7.0.1

\* Partner verified

### **Gateway Integration**

The following call servers have been tested with Spectralink 87-Series models.

Call Server	Gateway Partner	Platform	Gateway Software Version
Avaya Communication Manager v5.0-5.2	AudioCodes	Mediant 1000	6.60A.228.011

# **Copyright Notice**

© 2014-2016 Spectralink Corporation All rights reserved. Spectralink, the Spectralink logo and the names and marks associated with Spectralink's products are trademarks and/or service marks of Spectralink Corporation and are common law marks in the United States and various other countries. All other trademarks are property of their respective owners. No portion hereof may be reproduced or transmitted in any form or by any means, for any purpose other than the recipient's personal use, without the express written permission of Spectralink.

All rights reserved under the International and pan-American Copyright Conventions. No part of this manual, or the software described herein, may be reproduced or transmitted in any form or by any means, or translated into another language or format, in whole or in part, without the express written permission of Spectralink Corporation.

Do not remove (or allow any third party to remove) any product identification, copyright or other notices.

## Notice

Spectralink Corporation has prepared this document for use by Spectralink personnel and customers. The drawings and specifications contained herein are the property of Spectralink and shall be neither reproduced in whole or in part without the prior written approval of Spectralink, nor be implied to grant any license to make, use, or sell equipment manufactured in accordance herewith.

Spectralink reserves the right to make changes in specifications and other information contained in this document without prior notice, and the reader should in all cases consult Spectralink to determine whether any such changes have been made.

NO REPRESENTATION OR OTHER AFFIRMATION OF FACT CONTAINED IN THIS DOCUMENT INCLUDING BUT NOT LIMITED TO STATEMENTS REGARDING CAPACITY, RESPONSE-TIME PERFORMANCE, SUITABILITY FOR USE, OR PERFORMANCE OF PRODUCTS DESCRIBED HEREIN SHALL BE DEEMED TO BE A WARRANTY BY SPECTRALINK FOR ANY PURPOSE, OR GIVE RISE TO ANY LIABILITY OF SPECTRALINK WHATSOEVER.

## **Contact Information**

US Location 800-775-5330

Spectralink Corporation 2560 55th Street Boulder, CO 80301

info@spectralink.com

European Location +45 7560 2850

Spectralink Europe ApS Langmarksvej 34 8700 Horsens, Denmark

infodk@spectralink.com